CONCEPT-II

CONCEPT-II is a frequency domain method of moment (MoM) code, under development at the Institute of Electromagnetic Theory at the Technische Universität Hamburg-Harburg (<u>www.tet.tuhh.de</u>).

Overview of demo examples

The following demonstration examples for CONCEPT-II will be discussed in detail (\$CONCEPT: home directory of the package):

- 1. Wire loop, directory \$CONCEPT/demo/example1-wire-loop
- 2. Cylindrical monopole antenna radiating over a finite ground plate, directory \$CONCEPT/demo/example2-monopole-on-plate
- 3. Box with aperture and internal radiator, directory \$CONCEPT/demo/example3-box-with-aperture
- 4. Dielectric sphere in a plane wave field, directory \$CONCEPT/demo/example4-dielectric-sphere

Important: file names should never contain blanks.

Shortcuts: Help -> Navigation

In order to find out how CONCEPT-II works it is recommended to start with example 1.

General Proceeding

Sequence of steps to be carried out in all examples:

- Start of the CONCEPT-II program → click on the icon on your desktop → the last completed simulation is automatically loaded
- File Open Simulation choose the project directory
- Load the control file. Control files end with .sim, for example *example1-wire-loop.sim*. The **Simulation** tab at the left side of the GUI window is active:



- A *right click* on an item of the project tree selects it and opens a pull-down menu. Note that not all entries have a pull-down menu.
- Example: A right click on **Wires** opens a list according to the following figure:



- Selecting New wire file provides a window where to enter the wire data (beginning and end coordinates, radii etc.)
- The project tree includes four main sections:
 - 1. Setup of the structure (geometry, symmetry, surfaces wires etc.)
 - 2. Setup monitoring (specify field probes, current probes)
 - 3. Setup printing (use the default entries)
 - 4. Setup simulation (frequency sampling, type of excitation and solver to be used)
- Carefully enter the necessary data
- Run the simulation by left clicking on the button with the green circle icon 💽 in the top left corner of the GUI
- Once the simulation run (back end) has finished, click the **Post processing** tab and choose an appropriate button under the 'Compute Results' section. Hovering the mouse over an icon gives information on the type of action and purpose, respectively.

Discretization, creating surface patch meshes

- Activate the Cad tools tab at the left side of the CONCEPT-II GUI
- Click on one of the basic tools **v v v v** and discretize the corresponding surface type. Note that the box tool (first left icon) can also be used to generate plates, pyramids etc.
- After having created a proper mesh and/or wire structure click on the **Simulation** tab → The 'Project View' section appears with the simulation project tree left to the display area
 - Right click on the top item of the simulation project tee → select Load all files from 'CAD' (the corresponding files appear under the Wires and/or Surfaces entries of the simulation project tree)
 - Should changes on surface grids be necessary activate the Cad tools tab, then right click Geometry from simulation → Load simulation file(s) as demonstrated in the following figure:



Example 1: Wire Loop

\$CONCEPT/demo/example1-wire-loop

It is recommended to start from an empty directory and set up the simulation according to Fig 1.

The structure to be investigated is a quadratic wire loop, see the following figure. The side length is a=0.1 m, radii of wires: 1 mm, frequency: 1 MHz, voltage generator: 1 V.



Having loaded the file *example1-wire-loop.sim* the GUI looks like this (right click on **loop.wire** \rightarrow Edit wires):



Fig 1: Modifying and entering of wire data

Four straight wires are forming the loop; the coordinates are contained in the file *loop.wire*.

Wire files should be named xxx.wire or wire.xxx.

Surface files should be named accordingly xxx.surf or surf.xxx with xxx as an arbitrary name without blanks.

Enter the frequency: right click on Frequencies \rightarrow Single Frequency \rightarrow a sub-window opens \rightarrow enter 1 MHz, see Fig 2 \rightarrow OK



Fig 2: Entering the frequency

Setting the generator: right click **Excitation** \rightarrow **Voltage generator(s)** \rightarrow Select a wire by right click, the mouse pointer is turned into a cross when having picked the wire \rightarrow enter amplitude and phase as illustrated in Fig 3 \rightarrow **OK**

10	and a second second		
Po	Wires	CONCEPT-II Voltage Generators	n.
_	loop.wire		
S		Voltage generators for loop.wire (number of wires: 4)	
00			а.
p	Material parameter		
Ű	E-	Select a generator on by right click	
	Field probes		
ťa	Current probes		
da	Current probes on loop.wire	Wire number Wire position Amplitude (V) Phase (degrees)	
DO.	Current distributions	Generator 1 1 middle segmen 1 10 00	
-	Current distr. on loop.wire		
	Voltage probes		
	E E Cangential probes		
		Append 🕈 Total generators 1 🗘 Do	
	Print selection		
	Print wire currents into an ASCII file		
	Print red. v matrix into an ASCII file		
	- Print red. y matrix into a Touchstone f	ile 🖌 🗸 Apply 🗸 🗸 🐼 Cancel	
	🔄 🗌 Print red. y matrix into a binary file		
	🖻 🚺 Setup simulation		
	E Frequencies		
	- Single Frequency		
	Generator(s) on loop wire	Voltage generator(s)	
	Generator 1	Ports (power input/voltage input)	
	⊕ [a] ¹ Solver	Plane wave field	
	- LU decomposition with row pivoti		_
	- Single precision	Impressed wire current	
	Galerkin matching	RCS	
		Stochastic EM excitation	
		\neg	
		X	

Fig 3: Placing a voltage generator on a wire

Clicking on \bigcirc starts the solver. The equation system is set up; the electric field integral equation is turned into a linear system of equations which is then solved by LU decomposition.

Activating the **Log data** tab and clicking on **Concept-II-simulation** displays the contents of the log file *concept.out*:

```
* CONCEPT-II, Version 12.0
* (C) Copyright 1984-2014, TUHH, E-18
The current data file: wire-loop.sim
Wire information
_____
Wire attached to the ideal ground -> 0
Beginning of a connected wire -> neg. number of that wire is printed
End of a connected wire -> pos. number of that wire is printed
1 6: Beginning and end are attached to wire(s).
Connection(s) at the beginning: 4
Connection(s) at the end: -2
2 6: Beginning and end are attached to wire(s).
Connection(s) at the beginning: 1
Connection(s) at the end: -3
3 6: Beginning and end are attached to wire(s).
Connection(s) at the beginning: 2
Connection(s) at the end: -4
4 6: Beginning and end are attached to wire(s).
Connection(s) at the beginning: 3
Connection(s) at the end: -1
Frequency of step: 1 0.10000E+01 MHz;
Total number of wire current amplitudes: 36
```

*

Total number of patch current amplitudes: 0 Total number of unknowns: 36 Generator (wire): 1 Generator at the middle of wire 1 Input impedance (Ohm): 0.38559E-09 0.19453E+01 Inner impedance of the wire generator: 0.00000000 0.00000000 Amp. of the excitation voltage: 0.10000E+01 V Input power: 5.09463860E-11 Watt Total input power: 0.50946E-10 Watt

Current distribution on 1. wire in A (9 current functions)

Real part imag. part magnitude phase (degees) wire coord. (m) 0.10189E-09 -0.51406E+00 0.51406E+00 -0.90000E+02 0.55556E-02 0.10189E-09 -0.51405E+00 0.51405E+00 -0.90000E+02 0.16667E-01

 $\begin{array}{l} 0.10189 {\texttt E-09} \ -0.51405 {\texttt E+00} \ 0.51405 {\texttt E+00} \ -0.90000 {\texttt E+02} \ 0.83333 {\texttt E-01} \\ 0.10189 {\texttt E-09} \ -0.51406 {\texttt E+00} \ 0.51406 {\texttt E+00} \ -0.90000 {\texttt E+02} \ 0.9444 {\texttt E-01} \end{array}$

Current distribution on 2. wire in A (9 current functions)

```
Real part imag. part magnitude phase (degees) wire coord. (m)
0.10189E-09 -0.51406E+00 0.51406E+00 -0.90000E+02 0.55556E-02
0.10189E-09 -0.51406E+00 0.51406E+00 -0.90000E+02 0.16667E-01
0.10189E-09 -0.51406E+00 0.51406E+00 -0.90000E+02 0.27778E-01
0.10189E-09 -0.51406E+00 0.51406E+00 -0.90000E+02 0.38889E-01
...
```

Validation of the results

As a $<< \lambda$ we notice a current distribution with constant amplitude.

The equivalent circuit of our structure comprises

- 1. voltage generator (1V, f= 1MHz)
- 2. The radiation resistance of the loop
- 3. The self inductance of the loop

For the radiation resistance we have (analytical solution):

$$R_{rad} \approx 31200 \left(\frac{A}{\lambda^2}\right)^2 = 0.385 \cdot 10^{-9} \Omega$$
, with $A = 0.1 \text{m x } 0.1 \text{m}$, $\lambda = 300 \text{ m}$

This value is a very close to the real part of the input impedance, given by 0.38563E-09 Ω , see above. The self inductance of the loop can be computed by:

$$L_{analytical} \approx \frac{2\mu_0 a}{\pi} \left(ln \frac{a}{R} - 0.774 \right)$$

With a =0.1 m, R = 0.001 m we find: $L_{analytical} = 306,49 \text{ nH}$

For the CONCEPT-II result we have: $L_{numerical} = \frac{X}{\omega} = \frac{0.19453E+01}{2 \pi 10^6} = 309,6 \text{ nH}$

EM fields along a path or at points in space

The computed current distribution has automatically been saved onto the hard disk and is

available for the computation of electromagnetic fields. We want to compute the H field along a spatial path running through the center of the loop.

Activate the **Post processing** tab and click on **P**. A sub-window according Fig 4 opens. A line with start and end coordinates including 50 probes has been specified, see Fig 5.

Clicking on **Show path(s)** displays both the wire loop and the path in the display area.

			CONCEPT-II	Post Pr	ocessing		•
	Fields o	on rectangular s	urfaces, arbit	trary s	urfaces, along pa	aths	s, in points
General	Field probes						
CPUs			1				Load Save
🔘 E field	d	H field		О Е	nergy flux density		SAR
Show	rtime domain (inverse Fourier tra	ansform)				
Frequenc	y samples 1, m	nax. frequency: 1 N	ИHz				
🗌 All fre	equencies		Freq. no:				1 Freq in MHz: 1
🗌 All po	orts		Port number:				1
Shift of p	probes in direc	tion of normal vec	tors			*	
Method:	Conventional					\$	
							(!)

Fig 4: Selecting the H field for computation

						CON	CEPT-II Post Prod	essing				
		Fiel	lds on r	ectand	ular s	urface	s, arbitrary su	rfaces.	along pa	ths, ir	n points	
				-	, ,				51		1	
en	eral F	leid prob	bes									
Fie	ld along	g straigh	t path(s)									
	X start	Y start	Z start	X end	Y end	Z end	No. of probes					
1 0	0.05	0.05	-0.1	0.05	0.05	0.1	50					
Ap	pend	\$	At posit	lon	1		Ç Total numbe	rs 1			Do	Show path
Ар	pend	\$	At posit	lon	1		Ç Total numbe	rs 1			Do	Show path

Fig 5: Entering the path coordinates and the number of field probes

Clicking on **OK** starts the field computation. After the computation has finished a subwindow according to Fig 6 opens. We have data for the H field (default file name *hpath1.asc*) and choose 'Max. magn.'. **OK** provides the H field curve as a function of position as illustrated in (Fig 7).

CONCEPT-II Post Processing 🛞										
Field along straight path(s)										
Input file	8		H-Fi	eld-path	ns.h5			Browse		
Frequence	cy numbe	r:	1		* *	1 MHz				
Port num	nber:		1		* *					
Total nur	mber of li	nes:	1		*					
Real y	Imag. y	Mag	gn. y Real z Imag		Imag. z	Magn. z	Max. magn.	Result file		
1								h-path1.asc		
(4)							10			
	✓ Apply ✓ OK ◎ Cancel									

Fig 6: Choosing the field components to be displayed as a function of location

The peak is indicating the position where the path of probes goes through the loop plane.



Fig 7: The H field as a function of position. Click into the display area \rightarrow The ASCII data of the curve can be copied to a different file (see header of file for the content)

This default curve representation can be modified: Right click the following entry of the post processing tree: Path(s), see Fig 8. There are two alternatives to continue:

Proje	ect View D 🗵
Simulation	Compute Results
Post processing	Image: Show complete structure
a Cad tools	View results
Log dat	 Current/charge distribution 3D rad. diagram 2D rad. diagram
	Path(Curve selection Surfa Show results Time-domain responses

Fig 8: The post processing tree provides the possibility to quickly reload already computed results

- **1.** Curve selection \rightarrow Further field components can be selected to be displayed
- 2. Show results → The CONCEPT-II Gnuplot front-end opens. Already existing data can immediately be displayed. Individual changes with respect to curve representation, captions, and labeling can easily be carried out. Output formats are SVG, PNG and Postscript. Existing curve data can be loaded in addition for comparison.

EM fields in 2D regions

Activate the **Simulation** tab for changing the frequency to 1000 MHz (see Fig 9). Right click **Single frequency** \rightarrow **Set frequency** \rightarrow enter the frequency value into the subwindows which opens. We have to run the solver again clicking on \bigcirc .



Fig 9: Changing the frequency

Once we see the message 'Program finished' in the message box (bottom of the GUI) we continue with the post processing by clicking on the **Post processing** tab.

Example: 2D H field distribution at 1000 MHz

The H field distribution shall be displayed in the plane that intersects the wire loop. This plane is parallel to the YZ plane, shifted by half the edge length of the square loop (0.05cm).

Click on \bigcirc . Select the H field, see Fig 4. Then: Field probes \rightarrow Field in rectangular 2D region \rightarrow YZ plane \rightarrow Set '[X] in %', '[Z] in %', y position as shown in figure below \rightarrow Compute P1, P2, P3 \rightarrow the coordinate of the desired field region are computed. Enter the number of meshes between points P1,P2 and P3 and click on Show plane/Create surf.eh2d \rightarrow structure and diagram plane are depicted in the display area for control purposes.

Fields on recta	ngular surfaces, arbitrary	surfaces, along paths,	in points
Field in rectangular 2D region			
YZ plane 🗘	Compute	P1, P2, P3	
[Y] In % 600.00	ÇZ] in 9	600.00 ÷	x position 0.05
Coordinates (x,y,z) for P1	0.05	-0.25	-0.3
Coordinates (x,y,z) for P2	0.05	0.35	-0.3
Coordinates (x,y,z) for P3	0.05	-0.25	0.3
No. of meshes/wavelength:	8	P3	
Compute mesh			
No. of meshes between P1 and P2	: 32		
No. of meshes between P1 and P3	: 33	P1	P2
Show plane / Create surf.eh2d			
Name of result file:	H-Field-surf_eh2d.h5		
Print additionally into ASCII fil	e		

In the example a 32x32 grid is generated by the following entries (Fig 10) \therefore

Fig 10: Sub-window for specifying a rectangular 2D region for the computation of EM fields. The 2D region is described by a file having the CONCEPT-II surface patch data format (surf.eh2d). The result file is stored in HDF5 data format, see <u>https://support.hdfgroup.org/HDF5/</u> for information.

Click on **OK**. After the field computation has been finished the following windows appears, select **Field(s) at phases** (Fig 11)

	Field representation	
	Plot field distributions	
Name of result file	H-Field-surf_eh2d.h5	Browse
Extracted ASCII data file	Plot-H-Field-surf_eh2d.asc	
Frequency number	1 🗘 1000 MHz	Show values for all frequencies
Port number	1	
Representation	Field at phase(s)	
Number of phase intervals	16	
Phase In degrees (0 360) :	90.00 🗘	
Draw contour for rectan	gular 2D regions	
✓ Apply	√ ок	O Cancel

Fig 11: Sixteen phase intervals are recommended for a movie. In the general case it is frequently helpful to switch 'Draw contour for rectangular 2D regions' active

Click on **OK**. We see the distribution of the magnitude of the H field at phase 0° in the chosen rectangular field region.

Next it is recommended to do some scaling for a meaningful field representation. Note that there is a large variation in the magnitude of the computed field values. Right click onto the 'Scale widget' (right side of the display area). This gives:



Selecting Arrows circles... a window according to Fig. Fig 12 appears for arrow scaling.

Arrows	🗹 Log.	Length:	2.00	÷.
Circles	Log.	Diameter	1.00	* *
 Arrows in line form 	nat	Line width	1.0	*
Arrows in 3D	unicolored	÷		
Show small values	in linear scale			
Xtrans	0.1			
Ytrans	0.9			

Fig 12: Window for arrow scaling.

The default 'Length:' of arrows is set to 1. In our case we assume a logarithmic scaling for the length of the H field vectors and enhance their default length by a factor of 2. In addition it has been decided to draw all arrows in 3D mode to ensure a good visibility.

For an appropriate adjustment of the background colors right click on the 'Scale widget' again and choose **Color Scale...** \rightarrow a sub-window opens, see Fig 13.

CONCEPT-II Color Scale								
Scale values for surf.eh2d								
Minimum value: 7.48407	e-05	Maximum va	alue: 0.0	2				
Min/max control								
✓ Apply	~	ок	6	Cancel				

Fig 13: Scaling of the colors. Push the slider to the left or put in directly 'Maximum value:' 0.02 . All field amplitudes that are larger will be drawn in red

Vector scaling and color scaling gives the H field distribution as depicted in Fig 14 .



Phase in degrees: 90.00

Fig 14: Distribution of the H field in a plane parallel to the y-z plane at 90°. The colors represent the magnitude of the field vectors at this phase. Left click and drag \rightarrow the structure can be turned around in the display are. Rotate the mouse wheel to zoom in or to zoom out.

To start an animation the **Animate** button at the lower end of the post processing section has to be pressed. If the movie runs too fast set an appropriate 'Delay' (right to the animate button. Click on load the loop in addition to the field plot.

Wire current distribution at 1 GHz

It is assumed that the frequency is 1000 MHz.

Post processing tab \rightarrow click on $\not = a$ sub-window for configuring the current distribution appears.

Set the 'Number of phase intervals' to 16, which is a good number for showing an animation. Click on the **OK**. The colors along the wires indicate the distribution of the current amplitude. The loop current distribution at 0° is shown. Press **Animate** for a movie, enter an integer number under 'Delay' (for example 100) to slow down the animation speed.

- Make the wire lines thicker: **Options** → **Setting for wires in the line mode...**
- Wire numbers: Right click on wire.0 (post processing tree) \rightarrow Show labels \rightarrow Set a check mark on 'Show element numbers' \rightarrow OK

Click on \swarrow (tool bar) \rightarrow a sub-window opens. Select the wires by right clicks and press the **OK** button \rightarrow a gnuplot preview window appears, showing the corresponding current distributions at the specific phase.

Click on \swarrow (left side of the GUI under 'Compute Results') \rightarrow the sub window 'Current distribution, frequency domain' opens with additional possibilities for current representation.

Placing of lumped loads

Task: each wire shall be loaded in the center by a resistor of 50 Ω .

Activate the **Simulation** tab. Select the wire file by right click **loop.wire** \rightarrow **Set loads.**

Ideal ground	
🗆 Wires	
🖾 🗖 loop.wire	Edit wires
Check wires	Edic Wires
Surfaces	Set loads
Bodies	Set conductivity
Material parameter	
🗆 🗖 Setup monitoring	Rename
Field probes	Set color
Current probes	Show labels
Current probes on loop.w	
Current distributions	Unload file
Current distr. on loop.wire	

A windows where to set the loads opens.

e c Projec	Diles 1	101	= 📝 🖪 🗄 💷	CONCEPT-II Loa	ds	M ~	. 🍽 i ea	}	
Simulation			Loads	For loop.wire (numb	oer of wires: 4) click				
sing		Wire no.	Position	Circuitry identifier	Arrangement	R in Ohm	L in Microhenry		
Ces	Load 1	4	middle segmer~	series R,L 🗸	lumped ~	0.	0.		
bro	Load 2	3	middle segmer ~	series R,L 🗸	lumped ~	0.	0.		
ost	Load 3	2	middle segmer~	series R,L 🗸	lumped	0.	0.		
s	Load 4	1	middle segmer ~	series R,L	lumped ~	0.	0.		
Log data Cad tool	Append	oT ∨ E	otal loads Apply	1 &OK	`	• Ca	CONCEPT Set la R in Ohm: 5 ancel	oad value o Cancel	/
	= Cu = Vo	irrent dist Current d oltage pro Voltage p	ributions istr. on loop.wire bes robes on loop.wire	e			1	•••	/

Fig 15: Placing lumped loads on wires

- Right click on a wire \rightarrow the load symbol appears (green cylinder), a new load line appears in the 'CONCEPT-II Loads' window
 - Lumped loads can be placed at the center, at the beginning and at the end of a wire
 - Right clicking a top entry ('Position', 'Circuitry identifier',...) enables the global setting of a value in the respective column
 - Right clicking on the load line (Load 1 for example) enables to copy, insert, or delete the whole line

- Double clicking on a values \rightarrow individual values can be changed...
- Right click on '**R in Ohm**' \rightarrow **Set global** \rightarrow the small sub-window named 'CONCEPT-II Load Value' appears. 50 Ω will written into the whole column, notice (Fig 15).
- For voltages to be computed as a function of frequency (simulation project tree, section Setup monitoring) right click Voltage probes on loop.wire → Set probes
 → a sub-window with a list of loaded wires appears. Set the check mark to activate a voltage probe.

The corresponding voltage data will be available for post processing after the back end has finished.

Change the frequency to 1 kHz: Frequencies \rightarrow Single frequency \rightarrow enter 0.001 and run the simulation. Notice the output: Log data \rightarrow CONCEPT-II simulation

Computed loop current: (0.5e-2 -j 0.4...e-7) A.